

CONTROL PARTS PRICE LIST - Bottom Boards

PART #	MODEL #	DESCRIPTION
E53-4957	CIP-1	BOTTOM BOARD & HOUSING
E53-4974	CM3-2	BOTTOM BOARD & HOUSING
E53-4821	CPS-1	BOTTOM BOARD & HOUSING
E53-4881	CPS-2M	BOTTOM BOARD & HOUSING
E53-8823	CPS-3M	BOTTOM BOARD & HOUSING
E53-8654	DIP-1	BOTTOM BOARD & HOUSING
E53-8652	X1060/DIP-1	DIP-1 BOTTOM BOARD ONLY
E53-8123	ECS-1M	BOTTOM BOARD & HOUSING
E53-8223	ECS-2M	BOTTOM BOARD & HOUSING
E53-8323	ECS-3M	BOTTOM BOARD & HOUSING
E53-8423	ECS-4M	BOTTOM BOARD & HOUSING
E53-8523	ECS-5M	BOTTOM BOARD & HOUSING
E53-4323	EMC-2	BOTTOM BOARD & HOUSING
E53-9802	X1159/GE-32	BOTTOM BOARD ONLY
E53-5144	IC-47	BOTTOM BOARD & HOUSING
E53-5135	X1096/IC-410	BOTTOM BOARD ONLY
E53-5115	X1059/IC-610	BOTTOM BOARD ONLY
E53-9004	LX-641	BOTTOM BOARD & HOUSING
E53-9002	X1059/LX-641	BOTTOM BOARD ONLY
E53-9014	LX-642	BOTTOM BOARD & HOUSING
E53-9012	X1059/LX-642	BOTTOM BOARD ONLY
E53-9024	LX-644	BOTTOM BOARD & HOUSING
E53-9022	X1059/LX-644	BOTTOM BOARD ONLY
E53-9323	MC-22	BOTTOM BOARD & HOUSING
E53-9325	X1127/MC-22	BOTTOM BOARD ONLY
E53-3623	MST-1/MST-2	BOTTOM BOARD & HOUSING
E53-4523	MST-3	BOTTOM BOARD ONLY
E53-8854	MST-5	BOTTOM BOARD & HOUSING
E53-4992	RCM-40	BOTTOM BOARD & HOUSING
E53-3423	SA-10	BOTTOM BOARD & HOUSING
E53-5275	X1104/SVIM-1	BOTTOM BOARD ONLY
E53-5265	X1088/SVIM-1	BOTTOM BOARD ONLY
E53-4334	TLC-4200	BOTTOM BOARD & HOUSING
E53-8904	THO-2	BOTTOM BOARD & HOUSING
E53-9042	X1188/VPM-2	BOTTOM BOARD ONLY
E53-4962	VSM-2	BOTTOM BOARD & HOUSING
E53-4959	X188/VSM-2	BOTTOM BOARD ONLY
E53-8680	DIP-1	TRANSFORMER
E53-5276	SVIM	TRANSFORMER

"C" SERIES BOTTOM BOARDS

MAIN BOARDS DO NOT INCLUDE MICROPROCESSOR BOARD "CORE 50".

PART #	MODEL #	DESCRIPTION
E53-8324C	ECS-3C	MAIN BOARD ONLY
E53-8524C	ECS-5C	MAIN BOARD ONLY
E53-8651C	X1340/DIP-1C	MAIN BOARD ONLY
E53-8852C	X1336/MST-5C	MAIN BOARD ONLY
E53-4851C	CPS-2C	MAIN BOARD ONLY
E53-3422C	SA-10C	MAIN BOARD ONLY
E53-4454C	MVS-1C	MAIN BOARD ONLY
E53-8326C	CORE 50	MICROPROCESSOR BOARD