

BETTER AIR ENERGY RECOVERY VENTILATOR

The Better Air Exchanger automatically exchanges humid, stale air from inside with an equal amount of fresh outside air.

Two air streams enter the unit's core where they pass by each other, but do not mix since the individual aluminum plates in the core keep them separate. The EXHAUST fan draws stale, moist air from inside the building into the unit before sending this air to the outside. The INTAKE fan simultaneously draws fresh, dry air from the outside into the unit where it passes between the aluminum plates taking on the heat from the exhausting stale air.

The clean, dry, fresh pre-heated air is then circulated back into the building.



| PART # | MODEL # | INTAKE | | EXHAUST | | DIMENSIONS | | |
|----------|---------|--------|-----|---------|------|------------|-----|-----|
| | | DIA. | CFM | DIA. | CFM | L | W | H |
| E58-1500 | B1500 | 12" | 800 | 14" | 1500 | 69" | 23" | 24" |

PARTS

| PART # | DESCRIPTION |
|----------|---|
| E62-4032 | 12" DIA. INSULATED FLEX DUCTING PER FOOT |
| E62-4042 | 12" DIA. INSULATED FLEX DUCTING 25FT ROLL |
| E62-4033 | 14" DIA. INSULATED FLEX DUCTING PER FOOT |
| E62-4043 | 14" DIA. INSULATED FLEX DUCTING 25FT ROLL |
| E62-4093 | 14" DIA. NON-INSULATED FLEX TUBING PER FOOT |
| E62-4073 | 14" DIA. NON-INSULATED FLEX TUBING 25FT ROLL |
| E52-9513 | 14" MODULE |
| E52-9592 | 12" X 24" EXTENSION W/COLLAR |
| E62-1136 | 36" NYLON TIE STRAPS (UP TO 10" DIAMETER) |
| E62-1148 | 48" NYLON TIE STRAPS (UP TO 15" DIAMETER) |